



## **Husqvarna 120i 14" Chainsaw with battery and charger**

[Read More](#)

**SKU:** 967098102

**Categories:** [Husqvarna](#)

### **Product Description**

## **Husqvarna 120i 14" Chainsaw with battery and charger**

Looking for the perfect small chainsaw? The Husqvarna 120i is a lightweight, easy-to-use battery saw that's ideal for pruning branches and felling small trees. The intuitive keypad makes getting starting a breeze, while an inertia chain brake promises problem-free handling. The power-conserving savE™ mode ensures you won't run out of battery, and low noise levels let you work without disturbing the neighbors.

---